



E 41 Inside drum



E 45 Inner mid drum




E 40 Drum



E 46 Inner outside drum



E 43 Mid drum



E 42 Outside drum



E 44 Drum strap